PP-Slings for Timber Packages

Product information

For use: Sling for timber packages.
Design: Spliced eye in each end or spliced endless.



*In combination with synthetic/soft slings always use a spreader with a length that corresponds with 2/3 of the average length of the packages.
*Make sure to place the slings so that the center point is in the middle.
*Do not place soft slings so that they can roll over/on the metal straps on the package.
*Never store or leave pp-slings for longer periods outdoors as polypropylene then ages and looses in capacity.
*Slings should always be inspected by authorized personal prior to use.
*Check the weight of the packages, average weight is not enough max weight must be checked.
*Avoid placing slings on the quay where they can be over run by trucks etc, over run slings should immediately be discarded.
*Don't forget to calculate for angels and deduct all loses for these, as well as for small radius of hooks etc.

... Read more

Material: Polypropylene, 3 stranded rope.
Marking: The slings are provided with a brown label accordingly marked.

Safety factor: 6:1

CERTEX Svenska AB
info@certex.se
08-758 00 10

© November 2026 - All Rights Reserved

PP-Slings for Timber Packages

Lifting table

Part code	EWL mm	Diameter mm	WLL ton	Choke Hitch ton	Basket Hitch 0° ton	Basket Hitch 0-45° ton	Basket Hitch 45°-60° ton	Design	Colour
343100170550020	5.5	28	1.7	1.4	3.4	2.4	1.7	eye-eye	Black
343100340550020	5.5	28	3.4	2.7	6.8	4.8	3.4	endless	Green

CERTEX Svenska AB
info@certex.se
08-758 00 10
© November 2026 - All Rights Reserved