

PP-Slings for Timber Packages



Product information

For use: Sling for timber packages.

Design: Spliced eye in each end or spliced endless.

*In combination with synthetic/soft slings always use a spreader with a length that corresponds with 2/3 of the average length of the packages.

*Make sure to place the slings so that the center point is in the middle.

*Do not place soft slings so that they can roll over/on the metal straps on the package.

*Never store or leave pp-slings for longer periods outdoors as polypropylene then ages and loses in capacity.

*Slings should always be inspected by authorized personal prior to use.

*Check the weight of the packages, average weight is not enough max weight must be checked.

*Avoid placing slings on the quay where they can be over run by trucks etc, over run slings should immediately be discarded.

*Don't forget to calculate for angles and deduct all loses for these, as well as for small radius of hooks etc.

Material: Polypropylene, 3 stranded rope.

Marking: The slings are provided with a brown label accordingly marked.

Safety factor: 6:1

Part code	EWL mm	Diameter mm	WLL ton	Choke Hitch ton	Basket Hitch 0° ton	Basket Hitch 0-45° ton	Basket Hitch 45°-60° ton	Design	Colour
343100170550020	5.5	28	1.7	1.4	3.4	2.4	1.7	eye-eye	Black
343100340550020	5.5	28	3.4	2.7	6.8	4.8	3.4	endless	Green